

Эта страница является [переводом](#) страницы [Rpi](#). Перевод выполнен на 100%.

---

Другие языки:

English • [русский](#)

# iRidium Server for Raspberry Pi

Installing and setting up a server in a project i3 lite

**iRidium Sever for Raspberry Pi** is a program implementation of iRidium Server, which is launched as daemon or console application on a Raspberry Pi 3 controller


[Download iRidium server for Raspberry Pi3](#)



## Technical characteristics:

- [raspberrypi.org](http://raspberrypi.org)

iridium server connects to a hardware and send commands from a control panel to it. The control panels connect to the server to control the hardware through it, receive feedback, upload logs and database.




## Installation and configuration

To install iRidium server on Raspberry Pi download and install a required software:

1. [Download](#) (\*.deb) server file for Raspberry Pi
2. [Download](#) and install WinSCP
3. [Download](#) and install PuTTY


Connect and configure Raspberry Pi according to instructions from [raspberrypi.org](http://raspberrypi.org). Raspbian operating system must be installed on your device (officially supported operating system Raspberry Pi on the basis of Debian).

1 Launch **WinSCP**. In the program interface configure:



- File Protocol: SCP
- Host name: Raspberry Pi IP-address (to find out your address enter `ifconfig` in the pi console)
- Port number: 22
- User name: your login ("pi" by default)
- Password: your password ("raspberrypi" by default)


2 Save the settings with the Save key. Connect to Raspberry by pressing Login button . If the connection parameters are entered correctly, you will see a window on the right side of which is a menu for working with your Raspberry files:



3 Copy a(\*.deb) file, which you downloaded by link #1, in /home/pi folder


/home/pi				
Имя	Размер	Изменено	Права	
Desktop		06.05.2015 22:20:16	rw-r--r--	
python_games		27.01.2015 8:34:28	rw-rw-r--	
iridiumserver_1.0.0-5934_Pi.deb	2 609 KB	25.11.2015 7:19:32	rw-r--r--	

4 Launch **PuTTY**. In the program interface set up:




- Host Name (or IP address): IP-address of your Raspberry
- Port: 22 (default)
- Connection Type: SSH
- Saved Session: enter the name of the current setting and click Save
- Close window on exit: Only on clean exit

5 In the configured PuTTY click "Open" - the console will open. Enter login and password for connecting to the server.



*entered password does NOT displayed in the console - it is normal. Press "Enter", when you finish to enter*

6 If the login and password are correct, you will see a message about a successful connection to Raspberry



```
pi@raspberrypi: ~
login as: pi
pi@192.168.0.36's password:
Linux raspberrypi 3.18.11+ #781 PREEMPT Tue Apr 21 18:02:18 BST 2015 armv6l

The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
Last login: Wed Nov 25 05:35:45 2015 from unknowing.local
pi@raspberrypi ~ $
```


You can configure a static IP-address for Raspberry through Putty, [by instruction](#)

7 Install the package loaded into the Raspberry memory using the command:

```
sudo dpkg -i /<way_to the_package>/<package_name>.deb
```


For example:

```
sudo dpkg -i /home/pi/iridiumserver_1.0.0-5934_PI.deb
```



```
pi@raspberrypi ~ $ sudo dpkg -i /home/pi/iridiumserver_1.0.0-5934_PI.deb
```

Wait for the installation to complete. Do NOT turn off the power of the device. As a result, you will see:



```
pi@raspberrypi ~ $ sudo dpkg -i /home/pi/iridiumserver_1.0.0-5934_PI.deb
Selecting previously unselected package iridiumserver.
(Reading database ... 77851 files and directories currently installed.)
Unpacking iridiumserver (from .../iridiumserver_1.0.0-5934_PI.deb) ...
Create /var/lib/iRidium Server/
Setting up iridiumserver (1.0.0) ...
Creating autostart script...
update-rc.d: using dependency based boot sequencing
Starting server...
===== Start as Daemon =====
Main thread exit
pi@raspberrypi ~ $
```

After installation, the server runs as a daemon - the PuTTY log will NOT display any working

information, when you restart, the Raspberry Server will start automatically.

8 Launch the server from the iridiumserver directory. To do this, there are commands:

- `sudo ./iridium` - launch the server. When you close the console, the server closes
- `sudo ./iridium --hidden` - launch the server in the background (like a daemon). When the console is closed, the server does NOT close

Successful server startup:

```
pi@raspberrypi /iridiumserver $ sudo ./iridium

# ##### # # #
# # #
### # # ### ##### ### # # ### ##
# ##### # # # # # # # # # #
# # # # # # # # # # # #
# # # # # # # # # ## # # #
##### # # ##### ##### ##### ##### # # #

Server Version: 1.0.0:5934 (Nov 17 2015, 18:17:26)
Can't create ROOT_DIR /var/lib/iRidium Server/
Get Serial From /proc/cpuinfo 00000000d116d375 size: 16
Name raspberrypi(Server) Os Linux Family armv6l Model Raspberry PI
Doc Dir /var/lib/iRidium Server/Documents/
Cache Dir /var/lib/iRidium Server/Documents/
Log Dir /var/lib/iRidium Server/Logs/
Res Dir /iridiumserver/
DB Dir /var/lib/iRidium Server/DataBase/
[02-12-2015 13:01:45.000]      DEBUG   CORE      Core DoInit
[02-12-2015 13:01:45.000]      DEBUG   CORE      HWID Generation
```

An error may occur when you try to restart the server in the background:

```
# ##### # # #
# # #
### # # ### ##### ### # # ### ##
# ##### # # # # # # # # # #
# # # # # # # # # # # #
# # # # # # # # # ## # # #
##### # # ##### ##### ##### ##### # # #

Find file /tmp/irdaemon.pid with pid 2609. iRidium Daemon already running. Delete this file and kill process
iRidium NOT Started!
===== Exit from iRidium Server =====
```

In case of such an error, enter the command:

```
sudo rm /tmp/irdaemon.pid
```

```
pi@raspberrypi /iridiumserver $ sudo rm /tmp/irdaemon.pid
```

and restart the server (item 8).


9 The server is ready to work with the project

## Adding a server to the i3 lite project

You may add the server to the project in two ways:

1 Adding the server during the creation of the project


Launch the i3 lite application and start to create a project. The application will ask you to add a server. You need to agree.



You will see a window with the servers available on the local network. You need to select your server

Cancel	Servers	Refresh
	techruvb-VirtualBox(Server) 192.168.0.92	
	IRIDIUMUSER-PC(Server) 192.168.0.42	
	raspberrypi(Server) 192.168.1.185	
	TMP(Server) 192.168.0.45	
	DESKTOP-4SH2796(Server) 192.168.0.77	
	CREATORPC(Server)	

The application will ask you to enter the activation code using the QR scanner or manually




Now the server is added to the project.


2 Adding a server to the already created project

Open the project and go to the Config





Click the "server" tab and click the "Select Server" button.



You will see a window with the servers available on the local network. You need to select your server. The application will ask you to enter the pin code from the server (pin code is default 2007). After entering the PIN code, the server must be activated by clicking on the corresponding button