After getting access to the module driver (using the GetDevice function) you can refer to its commands: