

Module.getSubDevice()

to get the existing subdevice

Syntax

```
Module.getSubDevice(name)
```

input	sample	description
name	"MySubDevice"	type: String the name of the created subdevice
output		
Object		type: Object the SubDevice object

Example:

```
Module = B.getModule(ModuleID);  
NewSubDevice = Module.getSubDevice("MySubDevice"); // get created SubDevice
```