

## SubDevice.AddChannel

Adding a driver channel

### Синтаксис

```
SubDevice.AddChannel(Name, dataArray)
```

Название	Пример	Описание
Name	"Channel 1"	type: string channel name
dataArray		type: array data array specific for every driver
На выходе		
Boolean		type: Boolean success rate

### Пример

```
var l_oDevice = module.GetDevice("MyDevice"); //Getting a device
var l_oSubDevice = module.AddSubDevice("SubDevice 1", l_oDevice); //creating
a subdevice
l_oSubDevice.AddChannel("Channel 1", [0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
0x00, 0x00]);
```