

## SubDevice.AddTag

Adding a driver feedback channel

### Синтаксис

SubDevice.AddTag(Name, dataArray)

Название	Пример	Описание
Name	"Feedback 1"	type: string name of feedback channel
dataArray		type: array data array specific for every driver
На выходе		
Boolean		type: Boolean Success rate

### Пример

```
var l_oDevice = module.GetDevice("MyDevice"); //Getting a device
var l_oSubDevice = module.AddSubDevice("SubDevice 1", l_oDevice); //creating
a subdevice
l_oSubDevice.AddTag("Feedback 1", [0x00, 0x00, 0x00, 0x00]);
```