

SubDevice.AddVirtualTag

Add a virtual tag

Синтаксис

```
SubDevice.AddVirtualTag(Name, Value, [Edit], [smartID], [Hidden])
```

Название	Пример	Описание
Name	"Tag"	type: String name of subdevice virtual tag
Value	"Name"	type: String Tag value
Edit	true	type: Boolean Permission to edit tag
smartID		type: Number Parameter is under development. Set false.
Hidden	true	type: Boolean Feature of hidden tag
На выходе		
Object		type: Object Object of virtual tag

Пример

```
var l_oSubDevice = module.AddSubDevice("SubDevice 1"); //creating a subdevice  
var l_oTag = l_oSubDevice.AddVirtualTag("Name", "HDL-BUS", true);
```