

- To add an action for the subdevice.

You can use the following method to add actions for subdevices:

```
// Example of the function for an action
```

```
function changeLight(in_data){  
// To output the message about method activation  
IR.Log("changeLight run");  
// To output the sent parameters  
// lamp: 1, set: 100 - the message output in the log  
IR.JSONLog(in_data);  
// Send the received parameters to the device  
device.Send(in_data); }
```

```
// To add an action for the light
```

```
NewSubDevice.addAction({  
ActionType: "Simple", // Indicate the type of action  
Type: "script_call", // Indicate the type of action  
Param: {lamp: 1, set: 100}, // Send parameters, it is not required for  
activating the function  
Space: this, // Send the space for activationg the function - not required  
Method: changeLight, // Send the method  
Name: "Turn On" // Indicate the method name  
})
```