

Example of full program code:

```
IR.AddListener(IR.EVENT_MODULE_START, 0, function(moduleID, busID) {

    // Receiving the module copy
    // moduleID - the unique module identifier
    // Assigning the variable module
    var module = B.getModule(moduleID);
    // Form the subnet name and assign it to the variable netWorkName
    var netWorkName = "HDL-BUS Pro Network (UDP)" + busID;
    // Take the existing device and assign it to the variable device
    var device = IR.GetDevice(netWorkName);
    // Receiving the subnet address
    var subnetID = module.FromSubnetID;
    // Receiving the device number
    var deviceID = module.FromDeviceID;
    // Form the device name
    var deviceName = "HDL-MC48IPDMX.231";
    // Form the channel name
    var statusOnStartName = 'deviceName + ":" + "statusOnStart" + moduleID';
    // The separator used in commands
    var separator = 0x0;
    // The table of HDL command codes
```