

For example, 6-channel HDL dimmer contains 6 dimmable channels with which you can control 6 work groups. So it is reasonable to distinguish 6 SubDevices to be able to create actions, events and conditions for each work group.

It is required to have SubDevice in i3 lite modules: there can be 1 or many. Usually the quantity of SubDevices equals to the number of controller channels.