

Advanced Action is created on the basis of incomplete information about an action. If we continue the dimmer example, it looks like this. The dimmer is to be set at any value from 0 to 255, but it is not known what value is to be written, as well as the moment when this value is to be received.