

Let's consider an assignment of subdomain to the router via the paid service **No-IP**. There are 3 stages of configuration:

1. Register the subdomain on the site, which provide the DDNS service.
2. Set up the DDNS service on the router
3. Set up the Nat, PortForwarding service on the router