

In the module, you need to type subdeals, actions and virtual tags. Subdeivays need to be typed so that SmartAPI understands what kind of device (for example light or air conditioning) and could manage it. Modules in which devices are not specified for the type will not be managed using SmartAPI. Example of type indication in the module: