

1. "IP Address" - the local IP-address of the device on which you want to send commands from the Internet
2. "Public Port" - the port where you need to send the command from the Internet so it would come to the device
3. "Private Port" - the real hardware port that receives commands (it can be different from "Public Port")
4. "Traffic Type" - the allowed protocol for connection between the sender and receiver of commands (TCP or UDP)