

After a list of floors is created go to Rooms section and create a list of rooms in the project. To create a new room choose **add new room** in the menu. In the window that appears enter the name of a new room, choose a room icon and indicate which floor the new room belongs to.