

To install a module manually no additional script development is required. A user must go to iRidium store from the app, find a module, download it and enter data in the fields indicated in the Setup file. After it the app installs the module in the system with parameters entered by a user.