

Name	"HDL Relay"	type: String module name
ID	1	type: Number module ID
Icon		type: String module icon
Used	true	type: Boolean module usage flag
Hidden	false	type: Boolean hiddeb module flag
Smart	false	type: Boolean smart module feature
StoreID	102	type: Number module ID in iRidium store
SubDeviceCount	3	type: Number Number of subdevices
Version	1.0.4	type: String Module version
SetupCount	2	type: Number Number of objects with these settings for drivers
SubDeviceGroupCount	2	type: Number Number of object of subdevice groups
SettingsPopupName	"SettingsPopup 1"	type: String setting popup name of a module. A setting popup is created by a module developer to guarantee module work, if required
AuthorizationPopupName	"AuthorizationPopup 1"	type: String authorization popup. It is created by a module developer and it guarantees the work of modules, requiring authorization.
AuthorizationStatus	true	type: Boolean authorization flag. It is necessary to develop modules requiring authorization, if authorization status has to be indicated <ul style="list-style-type: none"> • true, if a user is authorized • false, if a user left the system
WorkMode		type: Number Module operation mode (panel, server). Constants: <ul style="list-style-type: none"> • IR.PROJECT_WORK_ONLY_PANEL_MODE: panel operation mode • IR.PROJECT_WORK_WITH_SERVER_MODE: server operation mode
ServerSupport	false	type: Boolean module supports working with server