

## Device.Connect

to connect to the peripheral device

### Syntax

```
IR.CreateDevice(IR.DEVICE_BLE_DEVICE).Connect()
```

<b>input</b>	<b>sample</b>	<b>description</b>
ID	IR.DEVICE_BLE_DEVICE	type: Number the identifier of the BLE scanner
<b>output</b>		
successful or not		type: Boolean successful

### Example:

```
var device = IR.CreateDevice(IR.DEVICE_BLE_DEVICE);  
device.Connect() ;
```

A device with the property Connectable = false cannot be connected. Also the device can break connection at any moment and not provide access for data reading and writing (to support the connection you are required to perform actions described in the device protocol from the manufacturer).

It activates the event: IR.EVENT\_ONLINE