

Device.WriteCharacteristic

to write the value of the characteristic

Syntax

```
IR.CreateDevice(IR.DEVICE_BLE_DEVICE).WriteCharacteristic(in_ble_cha)
```

input	sample	description
ID	IR.DEVICE_BLE_DEVICE	type: Number the identifier of the BLE scanner
in_ble_cha		type: Object the object of the characteristic

output

-

Example:

```
var device = IR.CreateDevice(IR.DEVICE_BLE_DEVICE);  
device.WriteCharacteristic(in_ble_cha);
```

It activates the event: IR.EVENT_CHARACTERISTIC_WRITE - the characteristic is written.

Notes:

- The Value property of the characteristic is used as a container of the new value for sending to the device;
- The format of the byte array for writing can differ from the array which can be received at reading;
- The characteristic is required to have CharacteristicPropertyWrite or related.