

## IR.EVENT\_ONLINE

the identifier of the event which is activated at connection to equipment

### Syntax

```
IR.AddListener(IR.EVENT_ONLINE, driver, function, [pointer]);
```

<b>input</b>	<b>sample</b>	<b>description</b>
driver	IR.CreateDevice(IR.DEVICE_BLE_DEVICE)	type: object the reference to the driver
function	function() {}	type: function the unnamed function or reference to the function
pointer	-	type: object the pointer to the object which serves the function (optional)

### output

-

### Example:

```
var device = IR.CreateDevice(IR.DEVICE_BLE_DEVICE)
IR.AddListener(IR.EVENT_ONLINE, device, function() {
  IR.Log("Online");
})
```