

The module driver is created in Project Device Panel. A module can contain only one driver in which connection data will be changed. If you need several drivers in one module, then add only the main one in Project Device Panel, the one which requires input of the IP-address. The rest are created via the script and they are given fixed data for connection. For example, the module of a media player with the Internet radio: the first driver will connect to the media player, the second - to the Internet.