


5.2. Adding to store

When a module is added from the store it requests device parameters (IP, port, etc.). For example, HDL GPRS, when it is added from the store, requests the following parameters:



To transfer these parameters to a module use the "Setup" script. Any script can be the "Setup" script - to achieve it tick the "true" check box in the script parameters:

Name	Setup_KNX_Color...
Global	False
Setup	True

For example, the "Setup" script for iRidium for HDL module looks this way: