

Check if a module has memory leaks. To do it, launch a module on a panel and let it work 24 hours. 24 hour later a module must continue to work correctly.