

Provider gives to your router the public static IP address **215.110.10.15**. You set a data redirection from external TCP port **8445** to internal TCP port **8443** on **192.168.0.100** host which is iRidium server IP address.