

7 Install the package loaded into the Raspberry memory using the command:

```
sudo dpkg -i /<way_to_the_package>/<package_name>.deb
```

For example:

```
sudo dpkg -i /home/pi/iridiumserver_1.0.0-5934_PI.deb
```

```
pi@raspberrypi ~ $ sudo dpkg -i /home/pi/iridiumserver_1.0.0-5934_PI.deb
```