

Go to the iridiumserver folder with the command `cd /iridiumserver` and re-enter `ls` to make sure that you are in the right directory

```
pi@raspberrypi / $ cd /iridiumserver/  
pi@raspberrypi /iridiumserver $ ls  
iridium  server.crt  server.key    
pi@raspberrypi /iridiumserver $
```