

Successful server startup:

```
pi@raspberrypi /iridiumserver $ sudo ./iridium
```

```
# ##### # # #  
# # #  
### # # ### ##### ### # # ### ##  
# ##### # # # # # # # # # #  
# # # # # # # # # # # #  
# # # # # # # # # # # #  
##### # # ##### ##### ##### # # #
```

Server Version: 1.0.0:5934 (Nov 17 2015, 18:17:26)

Can't create ROOT_DIR /var/lib/iRidium Server/

Get Serial From /proc/cpuinfo 00000000d116d375 size: 16

Name raspberrypi(Server) Os Linux Family armv6l Model Raspberry PI

Doc Dir /var/lib/iRidium Server/Documents/

Cache Dir /var/lib/iRidium Server/Documents/

Log Dir /var/lib/iRidium Server/Logs/

Res Dir /iridiumserver/

DB Dir /var/lib/iRidium Server/DataBase/

[02-12-2015 13:01:45.000] DEBUG CORE Core DoInit

[02-12-2015 13:01:45.000] DEBUG CORE HWID Generation