

Успешный запуск сервера:

```
pi@raspberrypi /iridiumserver $ sudo ./iridium

# ##### # # #
# # # # #
### # # ### ##### ### # # # #
# ##### # # # # # # # # # #
# # # # # # # # # # # #
# # # # # # # # # # # #
##### # # ##### ##### ##### # # #

Server Version: 1.0.0:5934 (Nov 17 2015, 18:17:26)
Can't create ROOT_DIR /var/lib/iRidium Server/
Get Serial From /proc/cpuinfo 00000000d116d375 size: 16
Name raspberrypi(Server) Os Linux Family armv6l Model Raspberry PI
Doc Dir /var/lib/iRidium Server/Documents/
Cache Dir /var/lib/iRidium Server/Documents/
Log Dir /var/lib/iRidium Server/Logs/
Res Dir /iridiumserver/
DB Dir /var/lib/iRidium Server/DataBase/
[02-12-2015 13:01:45.000] DEBUG CORE Core DoInit
[02-12-2015 13:01:45.000] DEBUG CORE HWID Generation
```